

# Inorganic Chemistry

## Experiment 1

### Synthesis of light sensitive potassium iron (III) oxalate






Max Shi, Jeremy Meyerberg, Marie Daschbach, Christian Teterycz

I pledge my honor that I have abided by the Stevens Honor System.


# Purpose

The purpose of this experiment is to illustrate the synthesis of iron oxalate, the “solvent exchange” method, and the stability of coordination complexes and the light sensitivity of iron oxalate.


Drawing of structure of the main compound or balanced chemical equation if synthesis is performed



Potassium Ferricyanide



Iron (II) Oxalate



Potassium Ferrioxalate

# Reagents and Major Product

Name	M.W. (g/mol)	Density (g/cm <sup>3</sup> )	Amount (mL / grams)	Moles	Hazards/Precautions	Role of Reagent
FeSO <sub>4</sub> ·7H <sub>2</sub> O Ferrous Sulfate Heptahydrate	278.01	1.90	3.6 grams	0.013	Harmful if swallowed, causes skin and eye irritation. May cause respiratory tract irritation.	Reactant
H <sub>2</sub> SO <sub>4</sub> Sulfuric Acid	98.08	1.83	Drops of 3 M		Very corrosive. Causes eye and skin burns. Also internal and respiratory burns. Handle in a fume hood and with gloves.	Reactant
H <sub>2</sub> C <sub>2</sub> O <sub>4</sub> ·2H <sub>2</sub> O Oxalic Acid Dihydrate	126.07	1.65	1.7 grams	0.013	Causes burns, harmful if swallowed, inhaled, or absorbed through skin.	Reactant
FeC <sub>2</sub> O <sub>4</sub> ·2H <sub>2</sub> O Iron (II) Oxalate Dihydrate	179.89	2.28			Can cause skin and upper respiratory tract irritation.	Precipitate
K <sub>2</sub> C <sub>2</sub> O <sub>4</sub> ·H <sub>2</sub> O Potassium Oxalate Monohydrate	182.24	2.08	3.5 grams	0.019	Can cause skin, eye, and digestive tract irritation. Also possible burns with contact.	Reactant
H <sub>2</sub> O <sub>2</sub> Hydrogen Peroxide	34.01	1.45	8 mL of 6%		A strong oxidizer and can be corrosive to the eyes, skin and respiratory system.	Reactant
K <sub>3</sub> Fe(CN) <sub>6</sub> Potassium Ferricyanide	329.24	1.89			Harmful if swallowed, causes skin and eye irritation. May cause respiratory tract irritation.	Product

# Procedure

## Part 1: Preparation of $\text{FeC}_2\text{O}_4 \cdot 2\text{H}_2\text{O}$

- **Solution A:** Weight 3.6g  $\text{FeSO}_4 \cdot 7\text{H}_2\text{O}$ , add several drops of 3M  $\text{H}_2\text{SO}_4$  (Why?) first and followed by water until  $\text{FeSO}_4 \cdot 7\text{H}_2\text{O}$  is totally dissolved;
- **Solution B:** Weight 1.7g  $\text{H}_2\text{C}_2\text{O}_4 \cdot 2\text{H}_2\text{O}$ , add water until sample is totally dissolved. Remove any insoluble substance.
- Slowly mix solution A and solution B. Boil the solution for 4 mins with constant stirring. Get rid of the supernatant, and wash the  $\text{FeC}_2\text{O}_4 \cdot 2\text{H}_2\text{O}$  precipitation with hot water for several times to remove left  $\text{SO}_4^{2-}$  (how can you know  $\text{SO}_4^{2-}$  is completely removed).

## Part 2: Preparation of $\text{K}_3[\text{Fe}(\text{C}_2\text{O}_4)_3]$

- Weight 3.5g  $\text{K}_2\text{C}_2\text{O}_4 \cdot \text{H}_2\text{O}$  and add 10 ml  $\text{H}_2\text{O}$  to dissolve the sample completely (heat may be needed).
- Add  $\text{K}_2\text{C}_2\text{O}_4$  solution to prepared  $\text{FeC}_2\text{O}_4$  crystals and then place the solution in 40 °C water bath. Slowly add 8 ml 6%  $\text{H}_2\text{O}_2(\text{aq})$  with continue stirring. Solution will become turbidity when all  $\text{H}_2\text{O}_2$  solution is added.
- Place one drop of reaction solution into a well on the assay plate, and then add another drop of  $\text{K}_3[\text{Fe}(\text{CN})_6]$ . Development of blue color indicates the presence of  $\text{Fe}^{2+}$ . More  $\text{H}_2\text{O}_2$  will be needed until all  $\text{Fe}^{2+}$  are converted into  $\text{Fe}^{3+}$ .
- Boil the solution with continuous stirring. Add 6 ml 0.5M  $\text{H}_2\text{C}_2\text{O}_4$  into the solution. Keep adding  $\text{H}_2\text{C}_2\text{O}_4$  until the solution is clear. Record added  $\text{H}_2\text{C}_2\text{O}_4$  volume.

# Procedure Cont.

## Part 3: Solvent-exchange precipitation

- Add 10 ml alcohol into the transparent  $K_3[Fe(C_2O_4)_3]$  solution.
- Place one end of a cotton string into the solution and tie another end of the string to a glass rod placed cross the mouth of the beaker.
- Cover the beaker with a paper and leave it at a dark place overnight.
- Collect  $K_3[Fe(C_2O_4)_3]$  crystals through filtration. Wash crystals with alcohol and dry the samples. Weight and calculate yield.


## Part 4: Light sensitivity test

Prepare 0.5 ml  $K_3[Fe(C_2O_4)_3]$  saturated solution.

Use the solution as the ink to write words or draw on the paper.

Expose the paper to light and observe the appearance of the words/drawings

# Flowchart




# Stepwise Procedure



# Preparation of $\text{FeC}_2\text{O}_4 \cdot \text{H}_2\text{O}$

1. Prepare solution A by weighing out 3.6 g  $\text{FeSO}_4 \cdot 7\text{H}_2\text{O}$ , adding several drops of 3M  $\text{H}_2\text{SO}_4$ , followed by water until  $\text{FeSO}_4 \cdot 7\text{H}_2\text{O}$  is completely dissolved.





# Preparation of $\text{FeC}_2\text{O}_4 \cdot \text{H}_2\text{O}$

2. Prepare solution B by weighing 1.7 grams  $\text{H}_2\text{C}_2\text{O}_4 \cdot 2\text{H}_2\text{O}$ , and adding water until sample is dissolved. Remove any insolubles from both solutions.



1.7 grams




Enough to  
dissolve



# Preparation of $\text{FeC}_2\text{O}_4 \cdot \text{H}_2\text{O}$

3. Slowly mix solution A and solution B. Boil the solution for 4 min with constant stirring. Decant supernatant, and wash  $\text{FeC}_2\text{O}_4$  precipitation with hot water several times to get rid of leftover  $\text{SO}_4^{2-}$



## 2.Preparation of $K_3[Fe(C_2O_4)_3]$

- Weight 3.5g  $K_2C_2O_4 \cdot H_2O$  and add 10mL  $H_2O$  to dissolve the sample completely (heat may be needed).
- Add  $K_2C_2O_4$  solution to prepared  $FeC_2O_4$  crystals and then place the solution in 40 °C water bath.

Weigh 3.5g  $K_2C_2O_4 \cdot H_2O$



Add 10mL  $H_2O$  to  
dissolve completely




Add  $K_2C_2O_4$  solution to  
 $FeC_2O_4$  and then place in  
water bath





Water bath  
40°C




- Slowly add 8 ml 6%  $\text{H}_2\text{O}_2$  with continue stirring. Solution will become turbidity when all  $\text{H}_2\text{O}_2$  solution is added.
- Place one drop of reaction solution into a well on the assay plate, and then add another drop of  $\text{K}_3\text{Fe}(\text{CN})_6$ . Development of blue color indicates the presence of  $\text{Fe}^{2+}$ .



Add 8 mL 6%  $\text{H}_2\text{O}_2$



Yields turbid solution




One drop of reaction solution


One drop of  $\text{K}_3\text{Fe}(\text{CN})_6$




If blue appears, there is  $\text{Fe}^{2+}$  present and  $\text{KFe}[\text{Fe}(\text{CN})_6]$  has formed




If no color change, no  $\text{Fe}^{2+}$  present




- More  $\text{H}_2\text{O}_2$  will be needed until all  $\text{Fe}^{2+}$  are converted into  $\text{Fe}^{3+}$ . Boil the solution with continuous stirring.
- Add 6 ml 0.5M  $\text{H}_2\text{C}_2\text{O}_4$  into the solution. Keep adding  $\text{H}_2\text{C}_2\text{O}_4$  until the solution is clear. Record added  $\text{H}_2\text{C}_2\text{O}_4$  volume.



Boil the solution with constant stirring



Add 6mL 0.5M oxalic acid




Add until solution is clear, and record added volume




# Solvent-exchange precipitation

1. Add 10 mL ethanol to the transparent  $\text{K}_3[\text{Fe}(\text{C}_2\text{O}_4)_3]$  solution. Place one end of a cotton string into the solution and tie another end of the string to a glass rod placed across the mouth of the beaker.



# Solvent-exchange precipitation


Cover the beaker with paper and leave it in a dark place overnight. Collect  $\text{K}_3[\text{Fe}(\text{C}_2\text{O}_4)_3]$  crystals through filtration. Wash crystals with alcohol and dry samples. Weigh and calculate yield.






# Part 4: Light Sensitivity Test


Prepare 0.5 ml  $\text{K}_3[\text{Fe}(\text{C}_2\text{O}_4)_3]$  saturated solution. Use the solution as the ink to write words or draw on the paper. Expose the paper to light and observe the appearance of the words/drawings



0.5 ml  $\text{K}_3[\text{Fe}(\text{C}_2\text{O}_4)_3]$   
saturated solution



Use solution as ink to  
write on paper



Expose paper to light and  
observe change



Observe color change

# Conclusion

The synthesis of iron oxalate was demonstrated using the “solvent exchange” method”. Also, the stability of coordination complexes and light sensitivity of iron oxalate were illustrated. The  $\text{FeC}_2\text{O}_4$  crystals were created using ferrous sulfate, sulfuric acid, and oxalic acid. The resulting precipitate was  $\text{FeC}_2\text{O}_4$  crystals. Sulfuric acid had to be added to prevent hydrolysis of the  $\text{Fe}^{2+}$  ions and to prevent the  $\text{Fe}^{2+}$  ions from being oxidized to  $\text{Fe}^{3+}$  ions.  $\text{K}_3[\text{Fe}(\text{C}_2\text{O}_4)]$  was prepared by adding potassium oxalate to the  $\text{FeC}_2\text{O}_4$  crystals and then heating them. For the solvent-exchange method, a cotton string was used with the solution because the complex binds more easily to the cotton string.

# Post Lab Questions

**Why a cotton string is needed in  $K_3[Fe(C_2O_4)_3]$  crystallization? What may happen if you do not do it like that?**

The complex binds more easily to the cotton string, allowing for better accumulation, which will make it easier to weigh it at the end to determine percent yield.

**Do you have any methods to erase the developed words/drawings on the paper in the light sensitive experiments?**

Adding a strong acid or a strong base to the solution would react with it and change the composition of the solution and therefore alter its pH. This would erase the words/drawings.